

## **DATA SHEET REMOVGEL**

### **REMOV GEL**

REMOV GEL is a cleaning product and can be used on all glass surfaces: glass, ceramic, bathroom sanitary ware.

Its use before applying TECNOCLEAN on used surfaces is essential.

It acts on more or less evident limestone deposits, removing them effectively, leaving a clean surface.

DO NOT use on aluminum and plastic as it may alter its appearance. It can be used on the chromium plating but do not leave to act more than 10 minutes, a longer permanence can sometimes change the appearance and / or the color of the surface.

Operating instructions for used surfaces:

Before starting the TECNOCLEAN treatment on ceramic or glass it is essential to remove all the limescale from the surfaces, using our ns. SUPERGLASS product in the case of strong encrustations, an anti-scale product or REMOV GEL

The application on limestone makes the treatment with TECNOCLEAN useless.

- Apply REMOV GEL - protect yourself with gloves - using a sponge:
- use an abundant quantity of the product that creates a certain thickness on the surface to be cleaned. If the thickness is thin, the correct reaction of dissolving the limestone does not happen
- Dab and leave for about 30 to 60 minutes, do not allow to dry
- rinse with water and dry the surface;
- check that the surface is completely clean from limescale; otherwise repeat the previous operations;
- proceed with the application of TECNOCLEAN on the perfectly clean and dry surface.

### **WARNINGS**

**CAUSES SERIOUS BURNS. THE PRODUCT MUST BE KEPT OUT OF THE REACH OF CHILDREN AND MUST BE USED ONLY WITH GLOVES, EYEWEAR, AND IN ARRIVED, PREVENTING DIRECT INHALATION AND CONTACT WITH EYES AND SKIN.**

Follow the product safety data sheet.